





PL/ Instrukcja montażu

EN/Installation instructions

DE/ Montageanleitung

FR/ Instructions de montage

ES/ Instrucciones de montaje

IT/ Istruzioni di montaggio


CZ/ Montážní návod


SK/ Návod na montáž


HU/ Szerelési utasítások


RU/ Инструкция по сборке













ul. Pascala 19 42-209 Częstochowa www.eko-light.com

EKO-LIGHT Sp. z o.o. Sp. k. \ +48 666 503 333

⊠ eko-light@eko-light.com















Wiring



Detection pattern



Settings

1. Sensitivity

Sensitivity can be adjusted by selecting the combination on the DIP switches for different applications.

1 -	100%
-	75%

		1	2	
	Ι	•	•	100%
1	II	•	0	75%
)	III	0	•	50%
	IV	0	0	10%

2. Hold-time

Hold-time refers to the time period that the light remains 100% on if no more movement is detected.

I – 58
II - 90s
III - 5mir

IV - 15min

	3	4	
Ι	•	•	5s
II	•	0	90s
III	0	•	5min
IV	0	0	15min

3. Daylight sensor

Different daylight threshold can be preset on DIP switches. Light will always turn on upon movement if daylight sensor is disabled.

I – Disable
II - 50Lux

1111	٠	OLUX
IV	-	2Lux

		5	6	
	Ι		•	Disable
	II	•	0	50Lux
J	III	0	•	10Lux
	IV	0	0	2Lux